

MERCEDES-BENZ CLIPS & FASTENERS **Sec. 22**

| | | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>20659 (201-997-22-81) White Nylon</p> <p>Hood & Trunk Moulding Insert Head Diameter: 7mm Stem Length: 6mm Fits Into 5.5mm Hole C, CL, CLK, E, SLK & S Class 1996 - On</p> <p>UNIT PACKAGE: 15</p> |  <p>16124 (001-988-20-81) Red Nylon</p> <p>Tubular Nut I.D.: 4.5mm, Length: 14mm Fits Into 9mm Hole</p> <p>UNIT PACKAGE: 50</p> |  <p>20404 (000-988-86-25) Natural Nylon</p> <p>Rocker Panel Moulding Screw Grommet Use With M4.2 (#8) Screw Class CL, E & S 1996 - On</p> <p>UNIT PACKAGE: 25</p> |
|  <p>20200 (001-988-77-81) Natural Nylon</p> <p>Moulding Insert Head Dia: 8mm Stem Length: 5mm Fits Into 7mm Hole Body Styles 202 & 210 1994 - On</p> <p>UNIT PACKAGE: 25</p> | <p>Twice Actual Size</p>  <p>13150 (123-997-03-81) Nylon</p> <p>Barrel Nut For 2mm Stud Fits Into 4mm Hole</p> <p>UNIT PACKAGE: 50</p> |  <p>20315 (673-988-00-25) Black Nylon</p> <p>Screw Grommet #8 (M4.2) Screw Size Head Diameter: 25mm Stem Length: 17mm Body Styles 124, 126, 170, 201, 202, 208 & 210 1991 - On</p> <p>UNIT PACKAGE: 15</p> |
|  <p>13141 (000-988-15-81) Red Nylon</p> <p>Moulding Insert</p> <p>UNIT PACKAGE: 50</p> |  <p>21499 (BMW: 51-44-7-780-135; Mercedes-Benz: 108-988-00-27) Natural Nylon</p> <p>Tubular Nut Stud Size: 7mm Head Diameter: 16mm Stem Length: 16mm Fits Into 8.5mm Hole BMW, Mercedes-Benz & Universal</p> <p>UNIT PACKAGE: 25</p> |  <p>20643 (000-997-91-86) Black Nylon</p> <p>Retainer Head Diameter: 13mm Stem Diameter: 6.5mm Stem Length: 11mm</p> <p>UNIT PACKAGE: 10</p> |
|  <p>13144 (000-988-55-81) Blue Nylon</p> <p>Moulding Insert</p> <p>UNIT PACKAGE: 50</p> |  <p>20647 (000-988-16-25) White Nylon</p> <p>Cowl Vent Nylon Nut M3.5 (#6) Screw Size Head Size: 9.5mm x 9.5mm Stem Length: 14mm Fits Into 6.5mm x 7mm Hole</p> <p>UNIT PACKAGE: 25</p> |  <p>21105 (001-988-03-25) Black Nylon</p> <p>Hood Insulation Retainer Head Diameter: 20mm Stem Diameter: 14mm Stem Length: 10mm Mercedes - Benz 2002 - On</p> <p>UNIT PACKAGE: 15</p> |
|  <p>13157 (000-987-10-81) White Nylon</p> <p>Moulding Insert</p> <p>UNIT PACKAGE: 50</p> |  <p>20646 (001-988-12-25) Natural Nylon</p> <p>M3.5 (#6) Screw Size Head Diameter: 12mm Stem Length: 20mm Fits Into 5.5mm Hole</p> <p>UNIT PACKAGE: 10</p> | |